

C7-ST-AUX

PROCAP BOOSTER



DUAL FUSE SYSTEM

Both the clamps and the accessory socket are protected by a safety fuse.

12-24V SWITCH

Easy to use switch allows the booster to be changed from 12V to 24V.

EXTERNAL CONNECTOR

A connector socket is fitted to the back of the unit allowing users to connect a number of industry starting connectors to the unit.



NATO



AVIO



COWBELL



12/24V

Model	Volts	Peak Amps (A)	Starting Amps (A)	# Of Batteries	Location of Fuse	Fuse (A)	Dimensions (cm)	Cable Diameter (mm ²)	Cable Reach (cm)	Unit Weight (KG)	Charger Voltage (V)	Charger Amps (A)	Vehicle Types
C7-ST-AUX	12/24	18000/9000	4400/3400	0	Clamp	500	25x25x50	50	170	13.2	230	3	

• 1,000,000 Cycles • -40 to +50C operating temperature • zero maintenance • light weight •